

90 = Special Equipment

Ordering No.	Call-out No.	Description of Part	Qty.
		Sidestand	
90 24 012	—	sidestand, complete	1
90 24 010	—	sidestand	1
90 24 170	—	rubber bumper	1
90 24 178	—	bushing	1
00 21 119	—	washer	1
99 45 165	—	cotter pin 3×20	1
90 24 174	—	spring	1
		Sidecar attachment	
90 20 172	—	sidecar attachments, complete set	1
90 24 184	—	ball stud	1
99 23 445	—	nut M 12×1.5—6 S pho.black.	1
99 45 175	—	cotter pin 3×25	1
90 20 182	—	screw with loop, front and rear	2
90 20 188	—	washer	2
99 32 130	—	lock washer B 12	2
99 22 135	—	nut M 12—6 S pho.black.	2
		Pillion seat and foot rests	
90 34 017	—	pillion seat	1
99 13 456	—	screw M 6×15—8 G, chrome plated	4
99 31 045	—	washer 6.4, chrome plated	4
99 36 135	—	star washer J 6.4 pho.	4
99 22 054	—	nut M 6—6 S pho.black.	4
40 34 150	—	foot rest	2
99 36 245	—	star washer J 12.5 pho.	2
99 13 890	—	screw M 12×25—8 G pho.black.	2
90 34 128	—	foot peg. rubber	2
		Dualseat	
90 34 025	—	dualseat (optional part No. 90 34 026)	1
99 13 457	—	screw M 6×15—8 G pho.black.	6
99 32 071	—	lock washer B 6	2
99 22 054	—	nut M 6—6 S pho.black.	2

Ordering No.	Call-out No.	Description of Part	Qty.
		Safety bars	
90 24 024	—	safety bars, complete set	1
90 24 158	—	safety bar	1
90 24 182	—	clamp	2
99 22 077	—	nut M 8—6 S pho.black.	8
99 32 091	—	lock washer B 8	8
90 24 190	—	engine mounting stud, front (long)	1
		Battery	
80 42 027	—	battery 6 V 16 ampere-hours	1
80 42 213	—	bottom plate	1
80 42 221	—	bottom pad	1
		Siren	
90 88 100	—	siren	1
90 88 110	—	switch cover	1
90 88 120	—	carrier for siren	1
80 42 131	—	vibration mount	3
90 88 124	—	pushbutton switch	1
90 88 128	—	brass ground connection	1
99 22 054	—	nut M 6 pho.black.	6
99 32 070	—	lock washer B 6	6
99 13 235	—	Screw M 5×15—8 pho.black.	2
99 22 036	—	nut M 5 pho.black.	4
99 31 034	—	washer 5.3 pho.black.	2
99 32 045	—	lock washer B 5	2
99 13 655	—	screw M 8×25—8 G pho.black.	2
99 32 091	—	lock washer B 8	2

Ordering No.	Call-out No.	Description of Part	Qty.
99 76 475	—	wire A 1.5 (×1080), brown	} deliverable only in running meters
99 76 474	—	wire A 1.5 (×1260), black	
99 76 478	—	wire A 1.5 (×1260), black-red	
99 76 474	—	wire A 1.5 (×160), black	
99 75 260	—	insulator tubing B 4×5 (×650), black, from pushbutton switch on handlebars, to clamp	
99 75 312	—	insulator tubing B 9×10 (×450), black, from end of rubber hose to siren	
Spotlight			
90 86 100	—	spotlight	1
90 86 114	—	spotlight carrier, left	1
90 86 115	—	spotlight carrier, right	1
Gasket set			
90 90 268	—	for R 50	1
90 90 269	—	for R 69	1
Tools			
90 90 172	—	cover (rubber), for pump	1
90 90 174	—	rubber insert for pump	1
90 90 176	—	rubber O-ring for pump	1
90 90 070	—	pump (without hose)	1
90 90 100	—	tool case (empty)	1
90 90 140	—	wrench for carburetor	1
90 90 188	—	cleaning cloth	1
90 90 108	—	open-ended wrench 8×10 SW	1
90 90 112	—	open-ended wrench 9×11 SW	1
90 90 116	—	open-ended wrench 12×14 SW, only for R 69	1
90 90 117	—	open-ended wrench 14×17 SW	1
90 90 122	—	open-ended wrench 19×22 SW	1
90 90 123	—	open-ended wrench 36×41 SW	1
90 90 124	—	wrench 12×14 SW	1

Ordering No.	Call-out No.	Description of Part	Qty.
90 90 125	—	wrench 21×22 SW	1
90 90 148	—	screwdriver, 3.5 mm blade width	1
90 90 149	—	screwdriver, 7 mm blade width	1
90 90 133	—	tire iron	2
90 90 135	—	pliers	1
90 90 129	—	wrench 14×19 SW	1
90 90 104	—	rod to remove wheel axle	1
90 90 138	—	round open-ended wrench	1
90 90 154	—	feeler gauge for valve clearance	1
90 90 162	—	patch kit	1
90 90 156	—	round open-ended wrench 17×27 SW	1
90 16 009	—	lock set (lock for steering column and tool box, with keys)	1
90 16 007	—	lock for steering column	1
90 16 105	—	key	2
90 16 101	—	cover	1
90 16 104	—	spring	1
90 90 031	—	tool kit for R 69 (without patch kit and pump)	1