

ROBERT BOSCH TERMINAL CODE SYSTEM

(BMW MOTORCYCLE APPLICATION)

<u>Terminal No</u>	<u>Application</u>
1	Ignition-primary (contact breaker-coil)
2	Ignition switch-ground (magneto ignition)
15	Positive, primary (ignition coil)
30	Positive from battery
31	Negative (return to battery neg. or ground)
51	Positive to light switch
54	Brake stop light-directional signal light
56	Lights, tachometer light
56a	High beam
56b	Low beam
57	Parking light
58	Lights (accessory, sidecar, rear)
61	Indicator charge light
D+	Positive-generation output (armature)
DF (F)	Generator field
B+	Battery (positive) on regulator